

ENGLISH

PLEASE READ THESE INSTRUCTIONS THOROUGHLY
This product must be assembled and should only be used for its intended purpose as described in these instructions. Use only for domestic cleaning.

Safety reminders.
DO NOT pick up liquids, hard or sharp objects, matches, hot or burning items or any other similar objects.
DO NOT use the appliance on or near open flames, candles, heaters, etc.
DO NOT use the appliance on or near flammable liquids such as cleaning fluids, petrol, etc., or their vapours.
DO NOT use the appliance on or near water, or other liquid cord to the wall bracket or charger is damaged.
DO NOT replace the nickel-cadmium battery pack with non-rechargeable batteries.
DO frequently clean the dust cup and filter assembly when picking up fine powder.
DO return the appliance to the wall bracket after use to recharge the batteries. Occasionally fully discharge the batteries to obtain maximum battery life.

CAR DRY ONLY MODEL
The Car cleaner model does NOT contain batteries and can only be operated via a car battery rated at 12 V d.c. This model is supplied with a cord fitted with a plug only suitable for insertion into a car cigarette/lighter socket supplied by the car battery (on some cars this is now labeled Power Outlet). The red indicator light is On when the ON/OFF switch is in the On position.

FEATURES 1

1. On/off Switch
2. Charging Light
3. Dust Cup Release Button
4. Crevice Tool
5. Dust Cup
6. Charging/Storage Base

Electrical requirements.

This Hoover appliance is supplied with a double insulated battery charger which is only suitable for insertion in a 230V (UK 240V) socket outlet. Ensure that the charger rating label matches your voltage supply.

STORAGE/CHARGING

TOOLS REQUIRED: SCREWDRIVER AND DRILL.
CHARGING/STORAGE BASE
Designed to sit in the charging base on a flat surface.
Diagram 1 1) Mount vertically (Diagram 2) 2) Mount horizontally. For tidy storage wrap excess cord on the back of the charging base and exit either side or bottom.

TO WALL MOUNT
1. Place the charging base against the mounting surface. Mark the centres of the holes.
2. Move base then drill 4.8mm holes.
3. Fit wall plugs.
4. Reposition base and insert screws, tighten screws and ensure base is fixed firmly to the wall.

UNIT STORAGE
1. Hang the unit by the handle and push firmly down onto the charging base.
2. Be sure that the red light is on to indicate charging.

CHARGING
NOTE: Use only the charger supplied with your cleaner to recharge.
IMPORTANT: BEFORE FIRST USE, CHARGE YOUR CLEANER FOR AT LEAST 24 HOURS.

When charging the Cleaner power switch must be Off. Keep the charger plugged into a socket outlet at all times. It is normal for the charger to become warm to the touch when charging. If the operating time reduces after repeated use, let the cleaner run until it stops, then recharge for 24 hours and repeat this monthly for best results.
Recharge the batteries in temperatures above 37°C or below 0°C.

HOW TO USE
TO USE: Remove cleaner from storage base, slide the power switch to the ON position. Empty and clean the unit and filter after each use or when the unit becomes full.

ATTACHMENTS
The crevice tool is permanently stored on board for your convenience.
To Use:
1. Flip crevice tool down to line up with nozzle and press up until securely in place.
2. To store crevice tool: Pull down until loose. Flip up towards cleaner and click back into storage area.

DUST CONTAINER & FILTER: REMOVAL AND REPLACEMENT
IMPORTANT! FOR BEST RESULTS CLEAN THE FILTER AFTER EACH USE
1. Depress the release button and remove dust cup assembly.
2. Hold dust container over waste bin and gently remove filter.
3. Empty dust container. Brush the dust and dirt off the filter or shake the filter inside the waste bin.
4. The filter may be washed in warm soapy water, make sure the filter is completely dry before replacing in your cleaner.
5. Replace the filter into the dust container and re-assemble the dust container to the cleaner.

End of product life battery disposal.
When the battery is no longer capable of holding a charge, the nickel-cadmium battery pack inside the product must be removed and disposed of in the correct manner.
Lift the product off the charging base, remove the dust container and the seven screws holding the main body and remove the battery pack. Ask your local council for details of battery disposal or return them to an authorised Hoover Service Dealer.

Guarantee Statement
Your new appliance is fully guaranteed for 12 months from the date of purchase against electrical/mechanical breakdown excluding:
a) Any faults which occur due to incorrect installation or misuse of the machine or accidental damage.
b) Damage, or interference with the machine by any person not authorised by the manufacturer to carry out service.
c) Any parts which are fitted to the machine which are not authorised manufacturers parts.
d) Non-domestic use of the machine.
e) Operation at incorrect voltage.

The guarantee applies to Great Britain and Northern Ireland only. The guarantee does not affect your statutory rights.

RECIPIENT A POUSSIERE ET FILTRE : POUR RETIRER ET REMPLACER
IMPORTANT! POUR DE MEILLEURS RESULTATS NETTOYEZ LE FILTRE APRÈS CHAQUE UTILISATION
1. Enfoncer le bouton de déjection et retirez l'ensemble récipient à poussière et filtre.
2. Retirez le récipient à poussière au-dessus de la poubelle et retirez doucement le filtre.
3. Videz le récipient à poussière. Brossez la poussière et la saleté du filtre à l'intérieur du filtre à la poubelle.
4. Le filtre peut être lavé dans de l'eau chaude savonneuse, assurez-vous qu'il est complètement sec avant de le remettre dans votre aspirateur.
5. Remettez le filtre dans le récipient à poussière et remontez le récipient à poussière sur l'aspirateur.

Mise au rebut à la fin de la durée de vie de la batterie
Lorsqu'une batterie n'est plus capable de maintenir la charge, le bloc de batteries Ni-Cd situé à l'intérieur du produit doit être retiré et éliminé de la manière correcte.
Solvez le produit du socle de charge, retirez le récipient à poussière et les sept vis qui maintiennent le corps principal et retirez le bloc de batteries. Demandez à votre mairie locale des informations sur la manière de jeter la batterie ou bien renvoyez-la à un centre de service après-vente Hoover agréé.

Déclaration de Garantie
Votre nouvel appareil est entièrement garanti contre les pannes électriques et mécaniques pendant 12 mois (24 mois pour la Suisse) à partir de la date d'achat, à l'exception de:
a) Tous défauts dus à une installation ou à une installation incorrecte, d'une utilisation incorrecte de l'appareil ou d'un dommage accidentel.
b) Toute personne non autorisée par le fabricant pour effectuer un service de réparation ou intervenir sur l'appareil.
c) Toutes pièces montées sur la machine qui ne sont pas les pièces originales du fabricant.
d) Une utilisation non domestique de la machine.
e) Une aspiration à la tension incorrecte.
Les points mentionnés ci-dessus n'affectent pas vos droits statutaires.
La facture d'achat ou le reçu doit être présenté pour toutes réclamations relevant des conditions de votre garantie.

FRANÇAIS

VEUILLEZ LIRE CES INSTRUCTIONS ATTENTIVEMENT
Ce produit doit être monté et utilisé uniquement pour l'objectif décrit dans ces instructions. À utiliser seulement pour un nettoyage domestique.

Rappels de sécurité.
N'ASPIREZ PAS de liquides, d'objets durs ou tranchants, d'objets en combustion tels que cigarettes, bougies, etc.
N'UTILISEZ PAS l'appareil pour aspirer des détergents contenant des ingrédients à base de dissolvant ou des produits liquides inflammables tels que nettoyants liquides, essence, etc., ou leurs vapeurs.
N'UTILISEZ PAS l'appareil si le matériel détecté ou si le cordon ou le câble d'alimentation est endommagé.
NE REMPLACEZ PAS le bloc de batteries Ni-Cd avec des batteries non rechargeables.
Nettoyez régulièrement le récipient à poussière et l'ensemble filtre lorsque vous aspirez de la poudre fine.
REMETTEZ l'appareil sur le socle du chargeur après son utilisation pour garantir la masse durable. Déchargez de temps en temps entièrement les batteries pour qu'elles aient une durée de vie maximale.

MODELE SEC POUR VOITURE UNIQUEMENT
Ce modèle d'aspirateur ne contient PAS de batteries et ne peut être alimenté qu'avec la batterie de voiture à un courant continu de 12 V c.c. Ce modèle est fourni avec un cordon dont la prise est adaptée pour l'insertion dans une prise à allume-cigare (adaptatrice pour l'insertion dans une prise à allume-cigare). La prise d'alimentation pour la batterie de la voiture (étiquetée: "Prise de sortie sur certaines voitures"). Le témoin lumineux rouge est allumé lorsque le commutateur MARCHE/ARRÊT est sur la position Marche.

CARACTÉRISTIQUES 1

1. Commutateur Marche/Arrêt
4. Outil suceur
2. Témoin de charge
5. Récipient à poussière
3. Bouton d'éjection du récipient
6. Socle de rangement/charge à poussière

Spécifications électriques.
Ce aspirateur Hoover Gerat est doté d'un chargeur de batterie à double isolation qui ne peut être inséré que dans une prise de courant de 230 V (R 240 V).

IMPORTANT: BEFORE FIRST USE, CHARGE YOUR CLEANER FOR AT LEAST 24 HOURS.
When charging the Cleaner power switch must be Off. Keep the charger plugged into a socket outlet at all times. It is normal for the charger to become warm to the touch when charging. If the operating time reduces after repeated use, let the cleaner run until it stops, then recharge for 24 hours and repeat this monthly for best results.
Recharge the batteries in temperatures above 37°C or below 0°C.

HOW TO USE
TO USE: Remove cleaner from storage base, slide the power switch to the ON position. Empty and clean the unit and filter after each use or when the unit becomes full.

ATTACHMENTS
The crevice tool is permanently stored on board for your convenience.
To Use:
1. Flip crevice tool down to line up with nozzle and press up until securely in place.
2. To store crevice tool: Pull down until loose. Flip up towards cleaner and click back into storage area.

DUST CONTAINER & FILTER: REMOVAL AND REPLACEMENT
IMPORTANT! FOR BEST RESULTS CLEAN THE FILTER AFTER EACH USE
1. Depress the release button and remove dust cup assembly.
2. Hold dust container over waste bin and gently remove filter.
3. Empty dust container. Brush the dust and dirt off the filter or shake the filter inside the waste bin.
4. The filter may be washed in warm soapy water, make sure the filter is completely dry before replacing in your cleaner.
5. Replace the filter into the dust container and re-assemble the dust container to the cleaner.

End of product life battery disposal.
When the battery is no longer capable of holding a charge, the nickel-cadmium battery pack inside the product must be removed and disposed of in the correct manner.
Lift the product off the charging base, remove the dust container and the seven screws holding the main body and remove the battery pack. Ask your local council for details of battery disposal or return them to an authorised Hoover Service Dealer.

Guarantee Statement
Your new appliance is fully guaranteed for 12 months from the date of purchase against electrical/mechanical breakdown excluding:
a) Any faults which occur due to incorrect installation or misuse of the machine or accidental damage.
b) Damage, or interference with the machine by any person not authorised by the manufacturer to carry out service.
c) Any parts which are fitted to the machine which are not authorised manufacturers parts.
d) Non-domestic use of the machine.
e) Operation at incorrect voltage.

The guarantee applies to Great Britain and Northern Ireland only. The guarantee does not affect your statutory rights.

RECIPIENT A POUSSIERE ET FILTRE : POUR RETIRER ET REMPLACER
IMPORTANT! POUR DE MEILLEURS RESULTATS NETTOYEZ LE FILTRE APRÈS CHAQUE UTILISATION
1. Enfoncer le bouton de déjection et retirez l'ensemble récipient à poussière et filtre.
2. Retirez le récipient à poussière au-dessus de la poubelle et retirez doucement le filtre.
3. Videz le récipient à poussière. Brossez la poussière et la saleté du filtre à l'intérieur du filtre à la poubelle.
4. Le filtre peut être lavé dans de l'eau chaude savonneuse, assurez-vous qu'il est complètement sec avant de le remettre dans votre aspirateur.
5. Remettez le filtre dans le récipient à poussière et remontez le récipient à poussière sur l'aspirateur.

Mise au rebut à la fin de la durée de vie de la batterie
Lorsqu'une batterie n'est plus capable de maintenir la charge, le bloc de batteries Ni-Cd situé à l'intérieur du produit doit être retiré et éliminé de la manière correcte.
Solvez le produit du socle de charge, retirez le récipient à poussière et les sept vis qui maintiennent le corps principal et retirez le bloc de batteries. Demandez à votre mairie locale des informations sur la manière de jeter la batterie ou bien renvoyez-la à un centre de service après-vente Hoover agréé.

Déclaration de Garantie
Votre nouvel appareil est entièrement garanti contre les pannes électriques et mécaniques pendant 12 mois (24 mois pour la Suisse) à partir de la date d'achat, à l'exception de:
a) Tous défauts dus à une installation ou à une installation incorrecte, d'une utilisation incorrecte de l'appareil ou d'un dommage accidentel.
b) Toute personne non autorisée par le fabricant pour effectuer un service de réparation ou intervenir sur l'appareil.
c) Toutes pièces montées sur la machine qui ne sont pas les pièces originales du fabricant.
d) Une utilisation non domestique de la machine.
e) Une aspiration à la tension incorrecte.
Les points mentionnés ci-dessus n'affectent pas vos droits statutaires.
La facture d'achat ou le reçu doit être présenté pour toutes réclamations relevant des conditions de votre garantie.

HOW TO USE
TO USE: Remove cleaner from storage base, slide the power switch to the ON position. Empty and clean the unit and filter after each use or when the unit becomes full.

ATTACHMENTS
The crevice tool is permanently stored on board for your convenience.
To Use:
1. Flip crevice tool down to line up with nozzle and press up until securely in place.
2. To store crevice tool: Pull down until loose. Flip up towards cleaner and click back into storage area.

DUST CONTAINER & FILTER: REMOVAL AND REPLACEMENT
IMPORTANT! FOR BEST RESULTS CLEAN THE FILTER AFTER EACH USE
1. Depress the release button and remove dust cup assembly.
2. Hold dust container over waste bin and gently remove filter.
3. Empty dust container. Brush the dust and dirt off the filter or shake the filter inside the waste bin.
4. The filter may be washed in warm soapy water, make sure the filter is completely dry before replacing in your cleaner.
5. Replace the filter into the dust container and re-assemble the dust container to the cleaner.

End of product life battery disposal.
When the battery is no longer capable of holding a charge, the nickel-cadmium battery pack inside the product must be removed and disposed of in the correct manner.
Lift the product off the charging base, remove the dust container and the seven screws holding the main body and remove the battery pack. Ask your local council for details of battery disposal or return them to an authorised Hoover Service Dealer.

Guarantee Statement
Your new appliance is fully guaranteed for 12 months from the date of purchase against electrical/mechanical breakdown excluding:
a) Any faults which occur due to incorrect installation or misuse of the machine or accidental damage.
b) Damage, or interference with the machine by any person not authorised by the manufacturer to carry out service.
c) Any parts which are fitted to the machine which are not authorised manufacturers parts.
d) Non-domestic use of the machine.
e) Operation at incorrect voltage.

The guarantee applies to Great Britain and Northern Ireland only. The guarantee does not affect your statutory rights.

RECIPIENT A POUSSIERE ET FILTRE : POUR RETIRER ET REMPLACER
IMPORTANT! POUR DE MEILLEURS RESULTATS NETTOYEZ LE FILTRE APRÈS CHAQUE UTILISATION
1. Enfoncer le bouton de déjection et retirez l'ensemble récipient à poussière et filtre.
2. Retirez le récipient à poussière au-dessus de la poubelle et retirez doucement le filtre.
3. Videz le récipient à poussière. Brossez la poussière et la saleté du filtre à l'intérieur du filtre à la poubelle.
4. Le filtre peut être lavé dans de l'eau chaude savonneuse, assurez-vous qu'il est complètement sec avant de le remettre dans votre aspirateur.
5. Remettez le filtre dans le récipient à poussière et remontez le récipient à poussière sur l'aspirateur.

Mise au rebut à la fin de la durée de vie de la batterie
Lorsqu'une batterie n'est plus capable de maintenir la charge, le bloc de batteries Ni-Cd situé à l'intérieur du produit doit être retiré et éliminé de la manière correcte.
Solvez le produit du socle de charge, retirez le récipient à poussière et les sept vis qui maintiennent le corps principal et retirez le bloc de batteries. Demandez à votre mairie locale des informations sur la manière de jeter la batterie ou bien renvoyez-la à un centre de service après-vente Hoover agréé.

Déclaration de Garantie
Votre nouvel appareil est entièrement garanti contre les pannes électriques et mécaniques pendant 12 mois (24 mois pour la Suisse) à partir de la date d'achat, à l'exception de:
a) Tous défauts dus à une installation ou à une installation incorrecte, d'une utilisation incorrecte de l'appareil ou d'un dommage accidentel.
b) Toute personne non autorisée par le fabricant pour effectuer un service de réparation ou intervenir sur l'appareil.
c) Toutes pièces montées sur la machine qui ne sont pas les pièces originales du fabricant.
d) Une utilisation non domestique de la machine.
e) Une aspiration à la tension incorrecte.
Les points mentionnés ci-dessus n'affectent pas vos droits statutaires.
La facture d'achat ou le reçu doit être présenté pour toutes réclamations relevant des conditions de votre garantie.

HOW TO USE
TO USE: Remove cleaner from storage base, slide the power switch to the ON position. Empty and clean the unit and filter after each use or when the unit becomes full.

ATTACHMENTS
The crevice tool is permanently stored on board for your convenience.
To Use:
1. Flip crevice tool down to line up with nozzle and press up until securely in place.
2. To store crevice tool: Pull down until loose. Flip up towards cleaner and click back into storage area.

DUST CONTAINER & FILTER: REMOVAL AND REPLACEMENT
IMPORTANT! FOR BEST RESULTS CLEAN THE FILTER AFTER EACH USE
1. Depress the release button and remove dust cup assembly.
2. Hold dust container over waste bin and gently remove filter.
3. Empty dust container. Brush the dust and dirt off the filter or shake the filter inside the waste bin.
4. The filter may be washed in warm soapy water, make sure the filter is completely dry before replacing in your cleaner.
5. Replace the filter into the dust container and re-assemble the dust container to the cleaner.

End of product life battery disposal.
When the battery is no longer capable of holding a charge, the nickel-cadmium battery pack inside the product must be removed and disposed of in the correct manner.
Lift the product off the charging base, remove the dust container and the seven screws holding the main body and remove the battery pack. Ask your local council for details of battery disposal or return them to an authorised Hoover Service Dealer.

Guarantee Statement
Your new appliance is fully guaranteed for 12 months from the date of purchase against electrical/mechanical breakdown excluding:
a) Any faults which occur due to incorrect installation or misuse of the machine or accidental damage.
b) Damage, or interference with the machine by any person not authorised by the manufacturer to carry out service.
c) Any parts which are fitted to the machine which are not authorised manufacturers parts.
d) Non-domestic use of the machine.
e) Operation at incorrect voltage.

The guarantee applies to Great Britain and Northern Ireland only. The guarantee does not affect your statutory rights.

RECIPIENT A POUSSIERE ET FILTRE : POUR RETIRER ET REMPLACER
IMPORTANT! POUR DE MEILLEURS RESULTATS NETTOYEZ LE FILTRE APRÈS CHAQUE UTILISATION
1. Enfoncer le bouton de déjection et retirez l'ensemble récipient à poussière et filtre.
2. Retirez le récipient à poussière au-dessus de la poubelle et retirez doucement le filtre.
3. Videz le récipient à poussière. Brossez la poussière et la saleté du filtre à l'intérieur du filtre à la poubelle.
4. Le filtre peut être lavé dans de l'eau chaude savonneuse, assurez-vous qu'il est complètement sec avant de le remettre dans votre aspirateur.
5. Remettez le filtre dans le récipient à poussière et remontez le récipient à poussière sur l'aspirateur.

Mise au rebut à la fin de la durée de vie de la batterie
Lorsqu'une batterie n'est plus capable de maintenir la charge, le bloc de batteries Ni-Cd situé à l'intérieur du produit doit être retiré et éliminé de la manière correcte.
Solvez le produit du socle de charge, retirez le récipient à poussière et les sept vis qui maintiennent le corps principal et retirez le bloc de batteries. Demandez à votre mairie locale des informations sur la manière de jeter la batterie ou bien renvoyez-la à un centre de service après-vente Hoover agréé.

Déclaration de Garantie
Votre nouvel appareil est entièrement garanti contre les pannes électriques et mécaniques pendant 12 mois (24 mois pour la Suisse) à partir de la date d'achat, à l'exception de:
a) Tous défauts dus à une installation ou à une installation incorrecte, d'une utilisation incorrecte de l'appareil ou d'un dommage accidentel.
b) Toute personne non autorisée par le fabricant pour effectuer un service de réparation ou intervenir sur l'appareil.
c) Toutes pièces montées sur la machine qui ne sont pas les pièces originales du fabricant.
d) Une utilisation non domestique de la machine.
e) Une aspiration à la tension incorrecte.
Les points mentionnés ci-dessus n'affectent pas vos droits statutaires.
La facture d'achat ou le reçu doit être présenté pour toutes réclamations relevant des conditions de votre garantie.

HOW TO USE
TO USE: Remove cleaner from storage base, slide the power switch to the ON position. Empty and clean the unit and filter after each use or when the unit becomes full.

ATTACHMENTS
The crevice tool is permanently stored on board for your convenience.
To Use:
1. Flip crevice tool down to line up with nozzle and press up until securely in place.
2. To store crevice tool: Pull down until loose. Flip up towards cleaner and click back into storage area.

DUST CONTAINER & FILTER: REMOVAL AND REPLACEMENT
IMPORTANT! FOR BEST RESULTS CLEAN THE FILTER AFTER EACH USE
1. Depress the release button and remove dust cup assembly.
2. Hold dust container over waste bin and gently remove filter.
3. Empty dust container. Brush the dust and dirt off the filter or shake the filter inside the waste bin.
4. The filter may be washed in warm soapy water, make sure the filter is completely dry before replacing in your cleaner.
5. Replace the filter into the dust container and re-assemble the dust container to the cleaner.

End of product life battery disposal.
When the battery is no longer capable of holding a charge, the nickel-cadmium battery pack inside the product must be removed and disposed of in the correct manner.
Lift the product off the charging base, remove the dust container and the seven screws holding the main body and remove the battery pack. Ask your local council for details of battery disposal or return them to an authorised Hoover Service Dealer.

Guarantee Statement
Your new appliance is fully guaranteed for 12 months from the date of purchase against electrical/mechanical breakdown excluding:
a) Any faults which occur due to incorrect installation or misuse of the machine or accidental damage.
b) Damage, or interference with the machine by any person not authorised by the manufacturer to carry out service.
c) Any parts which are fitted to the machine which are not authorised manufacturers parts.
d) Non-domestic use of the machine.
e) Operation at incorrect voltage.

The guarantee applies to Great Britain and Northern Ireland only. The guarantee does not affect your statutory rights.

RECIPIENT A POUSSIERE ET FILTRE : POUR RETIRER ET REMPLACER
IMPORTANT! POUR DE MEILLEURS RESULTATS NETTOYEZ LE FILTRE APRÈS CHAQUE UTILISATION
1. Enfoncer le bouton de déjection et retirez l'ensemble récipient à poussière et filtre.
2. Retirez le récipient à poussière au-dessus de la poubelle et retirez doucement le filtre.
3. Videz le récipient à poussière. Brossez la poussière et la saleté du filtre à l'intérieur du filtre à la poubelle.
4. Le filtre peut être lavé dans de l'eau chaude savonneuse, assurez-vous qu'il est complètement sec avant de le remettre dans votre aspirateur.
5. Remettez le filtre dans le récipient à poussière et remontez le récipient à poussière sur l'aspirateur.

Mise au rebut à la fin de la durée de vie de la batterie
Lorsqu'une batterie n'est plus capable de maintenir la charge, le bloc de batteries Ni-Cd situé à l'intérieur du produit doit être retiré et éliminé de la manière correcte.
Solvez le produit du socle de charge, retirez le récipient à poussière et les sept vis qui maintiennent le corps principal et retirez le bloc de batteries. Demandez à votre mairie locale des informations sur la manière de jeter la batterie ou bien renvoyez-la à un centre de service après-vente Hoover agréé.

Déclaration de Garantie
Votre nouvel appareil est entièrement garanti contre les pannes électriques et mécaniques pendant 12 mois (24 mois pour la Suisse) à partir de la date d'achat, à l'exception de:
a) Tous défauts dus à une installation ou à une installation incorrecte, d'une utilisation incorrecte de l'appareil ou d'un dommage accidentel.
b) Toute personne non autorisée par le fabricant pour effectuer un service de réparation ou intervenir sur l'appareil.
c) Toutes pièces montées sur la machine qui ne sont pas les pièces originales du fabricant.
d) Une utilisation non domestique de la machine.
e) Une aspiration à la tension incorrecte.
Les points mentionnés ci-dessus n'affectent pas vos droits statutaires.
La facture d'achat ou le reçu doit être présenté pour toutes réclamations relevant des conditions de votre garantie.

HOW TO USE
TO USE: Remove cleaner from storage base, slide the power switch to the ON position. Empty and clean the unit and filter after each use or when the unit becomes full.

ATTACHMENTS
The crevice tool is permanently stored on board for your convenience.
To Use:
1. Flip crevice tool down to line up with nozzle and press up until securely in place.
2. To store crevice tool: Pull down until loose. Flip up towards cleaner and click back into storage area.

DUST CONTAINER & FILTER: REMOVAL AND REPLACEMENT
IMPORTANT! FOR BEST RESULTS CLEAN THE FILTER AFTER EACH USE
1. Depress the release button and remove dust cup assembly.
2. Hold dust container over waste bin and gently remove filter.
3. Empty dust container. Brush the dust and dirt off the filter or shake the filter inside the waste bin.
4. The filter may be washed in warm soapy water, make sure the filter is completely dry before replacing in your cleaner.
5. Replace the filter into the dust container and re-assemble the dust container to the cleaner.

End of product life battery disposal.
When the battery is no longer capable of holding a charge, the nickel-cadmium battery pack inside the product must be removed and disposed of in the correct manner.
Lift the product off the charging base, remove the dust container and the seven screws holding the main body and remove the battery pack. Ask your local council for details of battery disposal or return them to an authorised Hoover Service Dealer.

Guarantee Statement
Your new appliance is fully guaranteed for 12 months from the date of purchase against electrical/mechanical breakdown excluding:
a) Any faults which occur due to incorrect installation or misuse of the machine or accidental damage.
b) Damage, or interference with the machine by any person not authorised by the manufacturer to carry out service.
c) Any parts which are fitted to the machine which are not authorised manufacturers parts.
d) Non-domestic use of the machine.
e) Operation at incorrect voltage.

The guarantee applies to Great Britain and Northern Ireland only. The guarantee does not affect your statutory rights.

RECIPIENT A POUSSIERE ET FILTRE : POUR RETIRER ET REMPLACER
IMPORTANT! POUR DE MEILLEURS RESULTATS NETTOYEZ LE FILTRE APRÈS CHAQUE UTILISATION
1. Enfoncer le bouton de déjection et retirez l'ensemble récipient à poussière et filtre.
2. Retirez le récipient à poussière au-dessus de la poubelle et retirez doucement le filtre.
3. Videz le récipient à poussière. Brossez la poussière et la saleté du filtre à l'intérieur du filtre à la poubelle.
4. Le filtre peut être lavé dans de l'eau chaude savonneuse, assurez-vous qu'il est complètement sec avant de le remettre dans votre aspirateur.
5. Remettez le filtre dans le récipient à poussière et remontez le récipient à poussière sur l'aspirateur.

Mise au rebut à la fin de la durée de vie de la batterie
Lorsqu'une batterie n'est plus capable de maintenir la charge, le bloc de batteries Ni-Cd situé à l'intérieur du produit doit être retiré et éliminé de la manière correcte.
Solvez le produit du socle de charge, retirez le récipient à poussière et les sept vis qui maintiennent le corps principal et retirez le bloc de batteries. Demandez à votre mairie locale des informations sur la manière de jeter la batterie ou bien renvoyez-la à un centre de service après-vente Hoover agréé.

Déclaration de Garantie
Votre nouvel appareil est entièrement garanti contre les pannes électriques et mécaniques pendant 12 mois (24 mois pour la Suisse) à partir de la date d'achat, à l'exception de:
a) Tous défauts dus à une installation ou à une installation incorrecte, d'une utilisation incorrecte de l'appareil ou d'un dommage accidentel.
b) Toute personne non autorisée par le fabricant pour effectuer un service de réparation ou intervenir sur l'appareil.
c) Toutes pièces montées sur la machine qui ne sont pas les pièces originales du fabricant.
d) Une utilisation non domestique de la machine.
e) Une aspiration à la tension incorrecte.
Les points mentionnés ci-dessus n'affectent pas vos droits statutaires.
La facture d'achat ou le reçu doit être présenté pour toutes réclamations relevant des conditions de votre garantie.

HOW TO USE
TO USE: Remove cleaner from storage base, slide the power switch to the ON position. Empty and clean the unit and filter after each use or when the unit becomes full.

ATTACHMENTS
The crevice tool is permanently stored on board for your convenience.
To Use:
1. Flip crevice tool down to line up with nozzle and press up until securely in place.
2. To store crevice tool: Pull down until loose. Flip up towards cleaner and click back into storage area.

DUST CONTAINER & FILTER: REMOVAL AND REPLACEMENT
IMPORTANT! FOR BEST RESULTS CLEAN THE FILTER AFTER EACH USE
1. Depress the release button and remove dust cup assembly.
2. Hold dust container over waste bin and gently remove filter.
3. Empty dust container. Brush the dust and dirt off the filter or shake the filter inside the waste bin.
4. The filter may be washed in warm soapy water, make sure the filter is completely dry before replacing in your cleaner.
5. Replace the filter into the dust container and re-assemble the dust container to the cleaner.

End of product life battery disposal.
When the battery is no longer capable of holding a charge, the nickel-cadmium battery pack inside the product must be removed and disposed of in the correct manner.
Lift the product off the charging base, remove the dust container and the seven screws holding the main body and remove the battery pack. Ask your local council for details of battery disposal or return them to an authorised Hoover Service Dealer.

Guarantee Statement
Your new appliance is fully guaranteed for 12 months from the date of purchase against electrical/mechanical breakdown excluding:
a) Any faults which occur due to incorrect installation or misuse of the machine or accidental damage.
b) Damage, or interference with the machine by any person not authorised by the manufacturer to carry out service.
c) Any parts which are fitted to the machine which are not authorised manufacturers parts.
d) Non-domestic use of the machine.
e) Operation at incorrect voltage.

The guarantee applies to Great Britain and Northern Ireland only. The guarantee does not affect your statutory rights.

RECIPIENT A POUSSIERE ET FILTRE : POUR RETIRER ET REMPLACER
IMPORTANT! POUR DE MEILLEURS RESULTATS NETTOYEZ LE FILTRE APRÈS CHAQUE UTILISATION
1. Enfoncer le bouton de déjection et retirez l'ensemble récipient à poussière et filtre.
2. Retirez le récipient à poussière au-dessus de la poubelle et retirez doucement le filtre.
3. Videz le récipient à poussière. Brossez la poussière et la saleté du filtre à l'intérieur du filtre à la poubelle.
4. Le filtre peut être lavé dans de l'eau chaude savonneuse, assurez-vous qu'il est complètement sec avant de le remettre dans votre aspirateur.
5. Remettez le filtre dans le récipient à poussière et remontez le récipient à poussière sur l'aspirateur.

Mise au rebut à la fin de la durée de vie de la batterie
Lorsqu'une batterie n'est plus capable de maintenir la charge, le bloc de batteries Ni-Cd situé à l'intérieur du produit doit être retiré et éliminé de la manière correcte.
Solvez le produit du socle de charge, retirez le récipient à poussière et les sept vis qui maintiennent le corps principal et retirez le bloc de batteries. Demandez à votre mairie locale des informations sur la manière de jeter la batterie ou bien renvoyez-la à un centre de service après-vente Hoover agréé.

Déclaration de Garantie
Votre nouvel appareil est entièrement garanti contre les pannes électriques et mécaniques pendant 12 mois (24 mois pour la Suisse) à partir de la date d'achat, à l'exception de:
a) Tous défauts dus à une installation ou à une installation incorrecte, d'une utilisation incorrecte de l'appareil ou d'un dommage accidentel.
b) Toute personne non autorisée par le fabricant pour effectuer un service de réparation ou intervenir sur l'appareil.
c) Toutes pièces montées sur la machine qui ne sont pas les pièces originales du fabricant.
d) Une utilisation non domestique de la machine.
e) Une aspiration à la tension incorrecte.
Les points mentionnés ci-dessus n'affectent pas vos droits statutaires.
La facture d'achat ou le reçu doit être présenté pour toutes réclamations relevant des conditions de votre garantie.

HOW TO USE
TO USE: Remove cleaner from storage base, slide the power switch to the ON position. Empty and clean the unit and filter after each use or when the unit becomes full.

ATTACHMENTS
The crevice tool is permanently stored on board for your convenience.
To Use:
1. Flip crevice tool down to line up with nozzle and press up until securely in place.
2. To store crevice tool: Pull down until loose. Flip up towards cleaner and click back into storage area.

DUST CONTAINER & FILTER: REMOVAL AND REPLACEMENT
IMPORTANT! FOR BEST RESULTS CLEAN THE FILTER AFTER EACH USE
1. Depress the release button and remove dust cup assembly.
2. Hold dust container over waste bin and gently remove filter.
3. Empty dust container. Brush the dust and dirt off the filter or shake the filter inside the waste bin.
4. The filter may be washed in warm soapy water, make sure the filter is completely dry before replacing in your cleaner.
5. Replace the filter into the dust container and re-assemble the dust container to the cleaner.

End of product life battery disposal.
When the battery is no longer capable of holding a charge, the nickel-cadmium battery pack inside the product must be removed and disposed of in the correct manner.
Lift the product off the charging base, remove the dust container and the seven screws holding the main body and remove the battery pack. Ask your local council for details of battery disposal or return them to an authorised Hoover

